

INSTALLING AIR3 AGAINST A WALL OR OTHER PODS- Best practices

Glass next to wall or another pod-

Follow instructions to build hoops, wall frames and front and back frame.
Leave approximately 24 inches to have room to install rear glass.
Pod can be built on furniture sliders or lifted to sliders.
Install rear glass using a small amount of glass cleaner for post fix seal.
Install rear top trip.
Leave roof sections and whiteboards off until pod is slid into position.
Make sure rear glass is clean as it will be inaccessible after moving.
Slide pod into final position.
Install jig to square pod.
Install roof sections, actuators and the fan.
Install exterior fabric panels.
Install interior fabric panel and whiteboards.
Plumb the front frame and install front glass, door & handle.

Fabric side next to wall or another pod

-

Follow instructions to build hoops, wall frames and front and back frame.
Leave approximately 24 inches to install exterior fabric panels.
Pod can be built on furniture sliders or lifted to sliders.
Install exterior fabric panels on the end that will be moved.
Slide pod to final position.
Install jig to square pod.
Complete built as normal.